



Depressurization of CO_2 -N₂ and CO_2 -He in a tube

<u>Svend Tollak Munkejord</u>, Han Deng, Anders Austegard, Morten Hammer, Hans L. Skarsvåg, Ailo Aasen

SINTEF Energy Research, Trondheim, Norway

http://www.elegancy.no/

ELEGANCY webinar, 2020-06-22

Outline of presentation



- Motivation
- ECCSEL depressurization facility
- Results
- Conclusions

Motivation





- Transport and injection of CO₂ is different from production of oil and natural gas, and this has implications on operation and design.
 - Operation close to critical point and triple point in some situations.

• Safety aspects are also different

- Running-ductile fracture: CO₂ boils and sustains a higher pressure on the opening pipe flaps.
- Potential clogging of vent lines due to dry-ice formation.
- Here we focus on an experiment to help development of models describing transient flow in pipes.

ECCSEL depressurization facility





ECCSEL depressurization tube

- Length 61.5 m
- Inner diameter 4 cm
- Specifically instrumented to capture decompression waves
 - 16 fast-response pressure transducers, sampling rate 200 kHz (here: 100 kHz)
 - -23 temperature sensors: 1 kHz
- Pressure up to 200 bar
- Initial temperature: 5–40 °C





Tube depressurization



Pressure: 12 MPa Temperature: 25 °C 100% CO₂ / CO₂ + 1.8% N₂ / CO₂ + 1.92% He

Æ





Pressure versus time for different positions



- CO₂ + 1.8% N₂
 - Full lines: Exp
 - Dashed: CFD (HEM) with EOS-CG
- Good agreement

Pressure-propagation speed





- CO₂ + 1.8% N₂
- Wave travelling upstream (sound speed vs flow speed).
- Calculated analytically assuming a 'long' tube and steady decompression wave.
- EOS-CG
 - Very good agreement for single-phase decompression speed



Pressure versus time for different positions



- CO₂ + 1.92% He
 - Full lines: Exp
 - Dashed: CFD (HEM) with Peng-Robinson (PR) EOS
- More regular behaviour in the two-phase region.
- Some discrepancy in single-phase decompression speed and 'plateau' level.

Pressure-propagation speed





- CO₂ + 1.92% He
- GERG-2008
 - Too high single-phase decompression speed
 - But right slope
 - Too high 'plateau pressure'
- Peng-Robinson (PR)
 - Adapted using VLE and PVT data
 - Too large single-phase slope
 - Probably too low 'plateau pressure'

Pressure-propagation speed





- Used e.g. for running-ductile fracture assessment.
- Abrupt change in wave speed at phase boundary.
- Impurities give
 - Higher 'plateau pressure' levels
 - Lower single-phase decompression speed.

Conclusion



- The ECCSEL depressurization facility has been put into operation.
 - Models for transient flow of CO₂ and CO₂-rich mixtures can be validated and further developed using the data acquired.
- The CO₂-mixture decompression behaviour is sensitive to N₂ and He in the 1% range. (Here: 1.8 and 1.9%).
- The homogeneous equilibrium model describes fast depressurizations quite well.
- We observe that the Peng-Robinson EOS gives an inaccurate speed of sound whereas EOS-CG is accurate for CO₂-N₂.
- Understanding the transient multiphase flow of CO₂ and CO₂-rich mixtures enables safe and efficient operation of CO₂ transport and injection systems.



Acknowledgement

ACT ELEGANCY, Project No 271498, has received funding from DETEC (CH), BMWi (DE), RVO (NL), Gassnova (NO), BEIS (UK), Gassco, Equinor and Total, and is cofunded by the European Commission under the Horizon 2020 programme, ACT Grant Agreement No 691712.





Contact: Svend Tollak Munkejord, svend.t.munkejord@sintef.no