



Statoil



Water content of high pressure natural gas

Data, prediction and experience from field

Kjersti Omdahl Christensen, Torbjørn Vegard Løkken, Even Solbraa, Cecilie Fjeld Nygaard, Anita Bersås

Outline

Background

Field experience

Phase behaviour

Experimental work

Thermodynamic model

Summary


Background

- Natural gas contains water in varying amounts dependent on upstream conditions
- Water in natural gas can create problems during transportation and processing
 - Gas hydrates
 - Ice formation
 - Increase corrosion potential
- Understanding of the phase behaviour of natural gas and its trace components is crucial for safe and efficient gas processing



Field experience

Platform process



- Water spec: $-18\text{ }^{\circ}\text{C}$ @ 69 barg
- Moderate dew point depression
- Triethylene glycol (TEG) used as water absorber
- Gas from TEG contactor contains TEG (g)


Rich gas flow →

Onshore process



- Cold processes
- Freezing of hydrocarbon/glycol/water solutions
- Hydrate formation in hydrocarbon/glycol/water solutions

Phase behaviour of natural gas with traces of water and TEG



Operating point, TEG contactor

CPA: Cubic plus association

EoS: equation of state

SRK: Soave-Redlich-Kwong

CPA-EoS

$$Z = \frac{V_m}{V_m - b} - \frac{a(T)}{RT(V_m + b)} - \frac{1}{2} \left(1 + \rho \frac{\partial \ln g}{\partial \rho} \right) \sum_i x_i \sum_{A_i} (1 - X_{A_i})$$


Classic
contribution
(SRK)

Contribution from
hydrogen bonding
(association and
solvation)

CPA-EoS is developed by CERE / DTU



Experimental set-up



A: Gas regulator

B: Shutdown valve

C: Valve

D: Pressure transmitter

E: Coil

F: Thermo element

G: El. heated pressure regulator

H: Safety valve

I: Metering valve

J: Flow meter


--- Heat tracing

M: Moisturizer

c: Condenser

Results

Data for the equilibrium water content in methane and a natural is available in the temperature range -20 to 20°C and pressures up to 150 bar



Comparison of experimental data for natural gas - water at 150 bar to stable and meta-stable phases predicted with the CPA-EoS

Summary

- ✓ Knowledge of phase behaviour of natural gas and its trace components is crucial for a safe and efficient production.
- ✓ CPA-EoS combined with thermodynamic models for the ice and gas hydrate phases gives excellent results for calculation of:
 - Equilibrium water content of natural gas
 - Water dew point temperature
 - Natural gas hydrate temperature
 - Ice precipitation temperature
 - Aqueous dew points

Thank you

Water content of high pressure natural gas

Kjersti O. Christensen

Researcher

kchr@statoil.com, +47 99 48 76 84

www.statoil.com