
Dynamic Water Management Studies by means of Perforated GDLs and In-situ ESEM Observations




Robert Alink, Dietmar Gerteisen,
Christian Sadeler, Christopher Hebling

Fraunhofer Institute for Solar Energy Systems ISE
Freiburg, Germany

Diagnostic Tools for Fuel Cell Technologies
24.06.2009, Trondheim

Overview



- Test scope: Examination of the water transport properties of laser perforated of gas diffusion layers
- In-situ single cell experiments and stack experiments
- Ex-situ visualizing of water transport in untreated and perforated GDLs in ESEM


The Fraunhofer Society



58 Institutes - 12 600 Employees – 1.2 Bio € Budget

7 Alliances

- Mikroelectronics
- Production Technology
- Information and Communication Technology
- Materials, Devices
- Life Sciences
- Surface Technology and Photonics
- Defense and Security Research



Fraunhofer ISE

Research & Development, Services

Research
Materials
Modelling
Methods




Development
Components
Products, Prototypes
Systems, Processes

Services
Consulting, Tests
Monitoring
Quality Assurance



Fuel Cell Systems

- Development of fuel cell systems, stacks and autonomously controlled systems
- Characterizing and modelling single cells, stacks and systems
- Control and safety technology




How can perforation of GDLs help to enhance the performance?

- Water is generated in the catalyst layer
- Water flows through small cavities
- Small filled cavities merge to larger cavities
- Void space gets filled by liquid water

As consequence:

- water hinders oxygen diffusion




How can perforation of GDLs help to enhance the performance?

- Pressure needed for through-plane transport of liquid water is higher than that for in-plane transport
- Water transport channels (WTCs) support the through-plane transport




Decreased saturation and increased oxygen diffusivity



Investigation of single cell



- Investigation of single cell with an active area of 1 cm^2
- Cathode GDL „under the channel“ was perforated by laser treatment
- Holes have a diameter of $80 \mu\text{m}$ and a gap distance of 1 mm



In-situ characterising of GDL water transport properties

Dynamic polarisation curves @


- different operating conditions
- sweep rate 10 mV/s show hysteresis effect



* without anode polarization


Improving the liquid water transport in the GDL

- Potential sweep measured with non-modified GDL




Improving the liquid water transport in the GDL

- Potential sweep measured with non-modified GDL
- Hysteresis knee due to flooding effects



Improving the liquid water transport in the GDL


- Potential sweep measured with non-modified GDL
- Hysteresis knee due to flooding effects
- Perforated GDL shows lowered pore flooding



Improving the liquid water transport in the GDL

■ Chronoamperometriy


700 ⇔ 400 mV



Improving the liquid water transport in the GDL

■ Chronoamperometriy


700 ⇔ 400 mV



Improving the liquid water transport in the GDL

- Chronoamperometriy


600 ⇔ 300 mV



Improving the liquid water transport in the GDL

- Chronoamperometriy

600 ⇔ 300 mV




Investigation of fuel cell stack

- Air cooled stack
- 6 cells
- Active area of 6 x 31 cm²



Cell stability at 0.71 A/cm²

- Stability test at 0.71 A/cm² and 63 °C




Cell stability at 0.71 A/cm²

- Stability test at 0.71 A/cm² and 63 °C
- Voltages of outer cells tend to collapse due to flooding
- Higher overall performance
- 3 times less purging steps



Increased stability
and performance




Polarisation curve

- Higher Voltage at constant current
- Less variation of single cell-voltage



Increased stability
and performance




Chronovoltammetry

- Higher Voltage after switching to higher current
- Lower temperature due to lower mass transport losses




Increased stability
and performance




Examination of degradation by freezing water in ESEM

- ESEM working in water vapor atmosphere
- All 3 phases of water possible by adjusting temperature and pressure




Examination of degradation by freezing water in ESEM

- Freeze / thaw cycling of GDLs




Examination of degradation by freezing water in ESEM

- Freeze / thaw cycling of GDLs




Examination of degradation by freezing water in ESEM

- Freeze / thaw cycling of GDLs
- Freeze / thaw cycling of MEAs




Examination of degradation by freezing water in ESEM

- Freeze / thaw cycling of GDLs
- Freeze / thaw cycling of MEAs
- Wet / dry cycling of MEAs as reference




Liquid water examination in ESEM

- ESEM working in water vapor atmosphere
- All 3 phases of water possible by adjusting temperature and pressure




Ex-situ visualization of liquid water breakthrough in ESEM


- Water is „sucked“ through a porous membrane and the GDL
- Visualization of water breakthrough near the GDL surface




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within an untreated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL




Transportation of water within a perforated GDL



Transportation of water within a perforated GDL



Transportation of water within a perforated GDL



Summary

- Single cell experiments consistent with stack experiments
- Significant increase in cell performance and stability achieved
- New method found to visualize water transport in GDLs in ESEM

